

MOVAX MODULAR SYSTEM - PILING HAMMERS

MOUNTING OPTIONS

The MOVAX piling hammers can be mounted directly onto the excavator (stick), onto MOVAX Multi-tool piling leader, or a third-party piling rig or crane.



Excavator-mounted



MOVAX multi-tool piling leader-mounted



Piling rig-mounted



Crane-mounted

Due to the modular design the same MOVAX piling hammer can be used on all the various carriers with minimum modifications. The mounting bracket, top cover and lower frame must be selected in accordance with the mounting option.

MOUNTING BRACKET

Each mounting option requires its own mounting bracket (except crane-mounting which do not require a mounting bracket).



Excavator-mounted



MPL-mounted



Piling rig-mounted

TOP COVER

The top cover is the same for the excavator- and multi-tool piling leader (MPL)- mounted DH piling hammer. When mounting the DH on a third party piling rig or on a crane a top cover with lifting lugs is required.



Excavator- &
MPL-mounted



Piling rig-/crane
-mounted

LOWER FRAME

The lower frame is the same for the excavator-, multi-tool piling leader (MPL)- and piling rig-mounted DH piling hammer. The crane-mounted piling hammer is equipped with a pile sleeve ("bell") with pile guides available separately for tubular steel piles and sheet piles.



Excavator-, MPL- &
piling rig-mounted



Crane mounted
(with Bell)

